

# RECTRA — Physical Field Reference Card (Printable Sheet)

Calibrated Field-Test Intelligence & Presumptive Evidence System (SIH26231)

RECTRA CALIBRATION REFERENCE CARD

Profile: DEMO-ASSAY-001 | Version: 1.0 | Card: v1.0

Place card flat under ambient lighting. Ensure full card is visible.

WHITE

L:95

BLACK

L:8

RED

L:45

GREEN

L:50

BLUE

L:35

PROFILE QR

GREY

L:55

TEST ZONE

Place chemical test reaction capsule/well here

RECTRA SIH26231 SYNTHETIC PROTOTYPE REFERENCE CARD – NOT AN OFFICIAL FORENSIC ARTIFACT

PHYSICAL SCALE VERIFICATION BAR: EXACTLY 50.0 MILLIMETERS

0 mm

50 mm

### IMPORTANT FIELD PRINTING & USAGE INSTRUCTIONS:

1. Print Scale: Print this sheet at 100% / Actual Size. Do NOT choose 'Fit to Page' or 'Scale to Fit'.
2. Scale Check: Measure the black bar above with a physical ruler. It MUST measure exactly 50 mm.
3. Paper Stock: Print on heavy, non-reflective matte card stock or matte photo paper.
4. ANTI-GLARE NOTICE: DO NOT laminate with glossy plastic pouches. Glossy lamination produces severe specular reflections that will trigger RECAPTURE REQUIRED on the RECTRA quality gate.
5. Reagent Placement: Position the transparent chemical reaction ampoule strictly within the central 'TEST REACTION ZONE' bounding rectangle without obscuring the 4 corner black fiducials or patches.